


THRUST COLLAR

NOTE:
ENCASE MEGALUG IN POLY-WRAP PRIOR TO PLACING CONCRETE.